

FRONT



LED Indicator

Speaker

Display
Full-color LCD and Glass-free

Volume up and down

Push to Talk or Alarm Button

Headset jack

Soft Keys: Access context-sensitive features

Back Key: Return to the previous menu or home screen

Navigation Keys: Scroll through menus and fields or move cursor

End Key:

- Ends or rejects call
- Powers the handsets on or off when held down for 2 seconds

Home Key: Returns you to the Home screen

OK Key: Selects menu items

Start Key

- Opens the dialer & initiates a call
- Answers an incoming call

Keypad: While in Multi Key Answer mode you can use any of these keys to answer an incoming call

USB Port

Charging pins

Noise Cancelling Microphone

BACK

- Noise Cancelling Microphone
- Speakerphone
- Battery pack